


## Wireless and Safety Edge Reset and Immediate Set



**Transmitter**

**Push button "PROGR"**